

# FleetSoft LI4278: Programming Barcodes for LI4278

Configuration name in Utility : FleetSoft LI4278  
Version : 001  
Last Modified : 19-Oct-12  
Windows Filename : Config File\_LI4278\_FleetSoft LI4278\_2012 10  
Plug-in Name : 19.scncfg  
LI4278-STANDARD SR MODELS-S-010



Instructions: Scan barcodes in order, starting with programming barcode 1.

1/5. Defaults



## Modify Data

2/5. Erase All Rules



3/5. Begin New Rule,1. Send ASCII Key <->,2. Send All that remains



4/5. 3. Send Extended Key <Enter>,Save Rule



## General Parameter Settings

5/5. Configuration File FleetSoft LI4278



## Notes:

Default configuration for FleetSoft TruckTracker and OnCommand.

## Firmware:

SAABIS00-001-R00

# FleetSoft LI4278: Programming Barcodes for LI4278

Configuration name in Utility : FleetSoft LI4278  
Version : 001  
Last Modified : 19-Oct-12  
Windows Filename : Config File\_LI4278\_FleetSoft LI4278\_2012 10  
Plug-in Name : 19.scncfg  
LI4278-STANDARD SR MODELS-S-010



---

## Supported Scanner Models for Plug-in :

CR0078-SC10001WR

CR0078-SC10007WR

CR0078-SC1009BWR

LI4278-SR20001WR

LI4278-SR20007WR

STB4278-C0001WR

STB4278-C0001WW

STB4278-C0007WR

STB4278-C0007WW